

Maple Walnut Fudge

1. Add cream powder to hot water and stir with a wire whip until there are no lumps.
2. Add dry ingredients.
3. Add no more than two (2) pounds of Maple Walnut fudge scraps.
4. Turn stove on high and stir constantly until ingredients all liquefy, then stir as needed.
5. Keep mixture low in the kettle while cooking.
6. Turn stove off so that temperature goes to exactly 237 degrees (+ or – adjustment for thermometer calibration, temperature, humidity and barometric pressure).
7. If you overshoot the temperature add $\frac{1}{4}$ qt. water and cook up $\frac{1}{2}$ degree **above the original finish temperature.**
8. Add butter and stir until it is melted.
9. Pour into bars on marble table.
10. Let cool to about 100 degrees.
11. Add flavoring and start paddling to mix in.
12. Add raw walnut pieces and continue paddling.

**For total recook batches add 1 qt. water and cook up $\frac{1}{2}$ degree plus extra $\frac{1}{2}$ degree if fudge was too soft.*